

# Leonardo DR nano

## The lightweight X-ray backpack solution for security operations

**The portable X-ray backpack system for radiographic testing in the security sector (e.g. EOD / IOD) - only with flat panel detector and tablet PC**

OR Technology's portable and digital system Leonardo DR nano delivers high-quality X-ray images ideally suited to detect even the smallest deviations during security operations.

Wireless, compact, lightweight, well-stowed and excellent image quality all describe the portable Leonardo DR nano system. The system weighs only approx. 9 kg and consists of two components: a wireless X-ray detector and a laptop/tablet PC plus accessories. The laptop (optionally tablet PC) complies with the latest standards and is equipped with the professional acquisition and control software, ORsecure. The Leonardo's straightforward user interface makes it easy for staff to generate excellent X-ray images. The unit is extremely versatile due to its low weight, compact design and practical carrying case.

One version of the Leonardo DR nano system are available:

- **Leonardo DR nano:** mobile X-ray system with wireless X-ray detector, format 35 x 43 cm



## System benefits

**Wireless:** quickly deployable and hassle free

**Small:** weight only approx. 9 kg (including laptop, accessories and detector), easy to transport – space-saving placement of the system components in a sophisticated, sturdy backpack

**Quick** to set up – once on site, the X-ray solution can be assembled quickly and easily

**Flexible:** backpack can also be converted into a carrying bag – shoulder straps can be hidden quickly and easily

**Perfectly** packaged: tidy and safe transport - components are stored in precisely fitting compartments that can be closed separately, all-round robust insulation material has a shock-absorbing effect.

**Excellent:** high-quality X-ray detector based on a caesium iodide (CsI) scintillator – top image quality even at low X-ray doses

**User-friendly:** self-explanatory OR Technology acquisition and control software ORinspect for non-destructive testing – easy operation even with changing personnel

**Fast:** shortly after taking the shot (6 - 8 seconds), the X-ray image is already available for viewing and diagnostic evaluation

**Accessibility:** integrated acquisition and control software offers a worldwide, fast and cost-effective exchange of information (via cloud or email) – in compliance with all safety regulations





## Dimensions



## Safe and sound:

- Sufficient space for the 14" x 17" flat panel detector with or without a protective cover and tablet PC
- Weight: only approx. 8 kg (complete with notebook, accessories and 14" x 17" flat panel detector)
- External dimensions 50 x 49 x 12 cm
- Padded and fitted with a sturdy protective frame
- Water repellant – safe in rainy conditions
- Many additional compartments to store the detector's battery charger, power cable of the tablet PC and other accessories
- Including shoulder strap (can be used as handle bag – the straps can be stored)



The product video of **Leonardo** system you can be found here: [www.or-technology.com/leonardo-nano-video](http://www.or-technology.com/leonardo-nano-video)




More information about **Leonardo DR nano** can be found here: [www.or-technology.com](http://www.or-technology.com)

# Advantages of acquisition and control software **ORinspect**

- Modern graphical user interface (GUI) adaptable to almost any language, **touchscreen** operation – to ensure quick and efficient work and a smooth workflow
- Free configuration** of testing objects already in the system (stipulations for testing images incl. X-ray value settings)
- Safe and quick **registration of ad hoc tests / inspections** (spontaneous test without detailed advance planning)
- Allows **switching between planned examinations** of a test object
- Images can be appended** to records even **after examinations** are complete
- User-defined macros** for recurring examinations
- To document the testing / inspection setup, **photos** can be attached to the test images
- Wireless remote control** of digital X-ray system, with display of worklist, image thumbnails and much more...
- Intuitive **multi-image concept** for SNR improvement

Automatic and manual **stitching** (combination of several images)



# Standard components of the **Leonardo DR nano**

## Transport backpack incl. accessories bag for chargers

- For 14" x 17" detectors with or without protective cover
- External dimensions 50 x 49 x 12 cm
- Padded and fitted with a sturdy protective frame including shoulder strap
- All important accessories have their own custom-fit compartments with separate closure



## Tablet PC or Notebook

SSD hard disk, 17" or 15" high-resolution display depending on equipment, Intel® CPU, at least 8 GB RAM, USB 3.0, Wireless LAN



## Direct radiography detector

35 x 43 cm (14" x 17") wireless

Wireless X-ray imaging! Fits into an existing X-ray system without requiring modification (in conformity with the X-ray film cassette), fast charging, long life batteries



(example)

## Battery charger including batteries

- fast charging, long life batteries, including battery charger
- charging time of battery: 3 hours



(example)

## Leonardo DR nano software package

with ORinspect, the professional acquisition and control software for the non-destructive X-ray testing with modern graphical user interface with basic software included:

- ORinspect DICONDE Send SCU
- ORinspect DICONDE Object CD
- ORinspect Cognition Optimised Processing



## Optional components to upgrade the Leonardo DR nano system

### Protection case

Available in various sizes for detectors 35 x 43 cm (14" x 17") and 24 x 30 cm (10" x 12"), including or excluding grid



### Amadeo P high-frequency X-ray units

Portable high-frequency X-ray units for high-quality X-ray images: Low weight and user-friendly operation enable various fields of application indoors and outdoors



## Specifications subject to revision without notice

The editor strives to impart correct and up to date information. The provided specifications are based on current knowledge and are subject to revision without notice. This brochure is subject to correction. The editor assumes no responsibility for the information being up to date, correct and complete.

All furnished logos, pictures and graphics are property of the particular company and subject to copyright of the licensor. Use, dissemination, distribution or copying of the pictures, logos or text compiled or processed by the editor is subject to our written consent. All rights reserved.


# OR Technology

[www.or-technology.com](http://www.or-technology.com) | X-perts in X-ray



OR Technology (Oehm und Rehbein GmbH), 18057 Rostock, Germany, Neptunallee 7c  
Tel. +49 381 36 600 500, Fax +49 381 36 600 555  
[www.or-technology.com](http://www.or-technology.com), [info@or-technology.com](mailto:info@or-technology.com)

Info hotline: +49 381 36 600 600



[Stamp of distribution partner]